

2006 SUMMER PROP INITIATIVE



ALWAYS EXAMINE AND CORRECT HAZARDOUS ROOF/RIB CONDITIONS

- Thoroughly examine roof/rib conditions wherever you work or travel, especially in areas that tend to become unstable.
- Know and follow your approved roof/rib control plan.
- Place yourself in a safe position when located near belts/equipment.
- Report unusual or unsafe conditions to other miners and mine management.

Unstable coal ribs should be taken down or supported.

